

Declaration of Installed Properties by Object

This declaration is evidence for [C22] "Property Value Range Processing Specification," [C23] "Device Object Superclass Processing Specification," [C24] "Profile Object Superclass Processing Specification," and [C25] "Node Profile Class Processing Specification."

For user-defined objects, each property inherited from the device superclass must be entered in the Declaration of Installed Properties. Also, mark the "SetI", "SetC", "Get", "INF_REQ" columns that may have function of receiving with "o".

Mark the "INFC", "INF", "Status Change Announcement" columns that may have function of sending process with "o".

Notes for "INF" column:

- Mark the "INF" column with "o" mandatory, if "Status Change Announcement" column is "o".
- Mark the "INF" column with "o", if it sends INF voluntarily.
- Don't mark the "INF" column, if it only sends response INF to a INF_REQ.

Notes: Numerals in the EPC Code field are hex values. You may enter ## only for 0x##.

Class Name **node profile**

Object code **0x0EF001**

Property Name	EPC Code	Installed Value	Size (Bytes)	Access Rule	Service Installation (o: Installed)						Status Change Announcement	Remarks
					SetI	SetC	Get	INF_REQ	INFC	INF		
operation status	0x80			Get			o	o			o	
standard version information	0x82			Get			o	o				
identification number	0x83			Get			o	o				
manufacturer code	0x8A			Get			o	o				
status change announcement property map	0x9D			Get			o	o				
set property map	0x9E			Get			o	o				
get property map	0x9F			Get			o	o				
number of self-node instances	0xD3			Get			o	o				
number of self-node classes	0xD4			Get			o	o				
instance list notification	0xD5			Anno				o		o	o	
self-node instance list S	0xD6			Get			o	o				
self-node class list S	0xD7			Get			o	o				

Use of user-defined area

0xF0	0xF1	0xF2	0xF3	0xF4	0xF5	0xF6	0xF7	0xF8	0xF9	0xFA	0xFB	0xFC	0xFD	0xFE	0xFF